

GENII CAMARO KIT INSTALLATION 70-78

This NVU kit is designed to be an aftermarket replacement for the original cluster. The kit installs in the factory location and uses the original bezel.

Remove negative battery terminal, chock wheels, wear safety goggles, and take all safety precautions.

Optional: remove steering wheel. Not required but will make the job much easier

Remove factory bezel, retain original fasteners (4).



Remove Headlamp, washer switches and lighter

Remove original cluster, release speedometer cable, wiring plug



Test fit cluster in dash, attach using original fasteners. Top 2 holes use original locations, bottom 2 use outer locations



Install OE bezel. Note location of gauges in relation to the openings. All instruments can be adjusted via the slotted bracket openings. Outer gauge fore/aft can be achieved with 1/4" spacers included in package. If needed entire bracket can be brought rearward in vehicle by swapping the mounting brackets to the back.

Once desired fit is achieved, tighten all back clamps securely.



Install senders and wire according to instruction booklet. Wire indicators as needed, red is 12V+, black ground



NEW VINTAGE USA
2415 BURDETTE
FERNDALE, MI 48220
248.2594964 PHONE
248.656.8291 FAX
info@newvintageusa.com
www.newvintageusa.com