



Part Number M9015

**LED Digital Voltmeter
Instructions**

WIRING INSTRUCTIONS

Connect the **BLACK** ground wire directly to the engine block.

Connect the **RED** wire to a switched +12 volt source (ignition circuit).

Connect the **PURPLE** wire to the headlight circuit to dim the LEDs 50% when the headlights are on. Do not connect to the dash light rheostat control wire or the dimming feature will not work properly. Connect the PURPLE wire to ground for permanent, maximum brightness.

If you have any further questions, please call us on 440-210-7646 and ask for Technical Support. Our business hours are 10 am to 6 pm EST.

Thank You,

Intellitronix Corp.