



Part Number M9013 and M9113

## LED DIGITAL WATER TEMPERATURE GAUGE

### Instructions:

#### WIRING INSTRUCTIONS

Connect the **BLACK** ground wire directly to the engine block if possible. For the most accurate reading, connect the gauge ground wire as close to the sender as possible.

Connect the **RED** wire to a switched +12 volt source (ignition switch).

Connect the **PURPLE** wire to the headlight switch to dim the LEDs 50% when the headlights are on. However, do not connect to the dash light dimming rheostat control wire – the dimming feature will not work properly. Connect the **PURPLE** wire to ground for permanent, maximum brightness.

Connect the **BLUE** wire to the temperature sending unit.

If you have any further questions, please call us on 440-210-7646 and ask for Technical Support. Our business hours are 8 am to 5 pm EST.

Thank You,

**Intellitronix Corp.**